


STANDARD PANEL BRACKET FIXING DETAIL

SCALE: 1:3.5



ADJUSTABLE PANEL BRACKET FIXING DETAIL SCALE: 1:3.5

## General Notes

All dimensions are in millimetres.

- 2. Drawings are not necessarily to scale
- Check www.boundaryline.co.nz to ensure you have the most recent edition of this publication.

## Fixing Notes

- All coach screws and bolts to be pre-drilled according to NZS 3603:1997
- 2. When fixing self-drilling screws, ensure low torque setting to avoid thread stripping. A battery drill is recommended for self-drilling screws DO NOT use an impact driver.

## Corrosion Zones

There are four corrosion zones in New Zealand that relate to the severity of exposure to wind-driven salt. See maps in figure 4.2 of NZS 3604:2011 (or online search 'BRANZ Maps') to determine the corrosion zone of the installation location and appropiate fixing option required.

ı				
	Zone	Risk Level & Location	Fixing Type	
	Zone B	Low risk	Hot-dip Galvanised	
I	Zone C	Medium risk	Hot-dip Galvanised	
	Zone D	High risk, all offshore islands, locations within 500m of coastline including harbours, locations within 100m of tidal estuaries and sheltered inlets.	316 Stainless Steel	
	Zone E	Very high risk, locations described in Zone D, beachfronts and seaside locations.	316 Stainless Steel	

## Existing Support Sturcture

- Supporting structures as not covered by these drawings unless specific requirements are detailed.
- Supporting structures are by others and must comply with the New Zealand Building Code.
- 3. If unsure of existing structure compliance, seek professional advice.



Terranota Ltd. P.O. Box 1703 Invercargill 1703 Telephone: 0800 002 725 Fax: 03 215 8248 Email: sales@fentec.co.nz

Email: sales@fentec.co.nz Website: www.fentec.co.nz

TITLE

FENTEC
BARRIER BALUSTRADE
CODE: FABBP1224 and
FABRP1224
1200 HIGH

1200111011				
SCALE		SIZE	DRAWING NO	
1:25		A4	FABBP1224	
REV.	DATE IS	SUED	(1H) ET	
Α	20	020-05-21	1 of 1	